

CDI's Installation Recommendations:

CDI RECOMMENDS THAT ALL BASE SHOWER PANS BE INSTALLED WITH A CLEAT AROUND THE PERIMETER OF THE ALCOVE TO SUPPORT AND LEVEL THE BASE.

THE FLANGE AROUND THE TOP OF THE BASE SHOULD BE SECURED TO THE WALL STUDS WITH SCREWS.

THE FOOT ON THE BASE IS FOR INSPECTION AND HANDLING NOT FOR SUPPORT OR LEVELING.

****TUB/SHOWERS/SHOWER BASES WILL NEED TO BE LEVED UP AT TIME OF INSTALLATION.
RECOMMEND A CLEAT TO LEVEL UP THE SHOWER BASE.**